

Autofocus Camera with Liquid Lens

Pixelink has developed a family of USB 3.0 autofocus cameras that seamlessly integrate with liquid lenses providing you with cutting-edge solutions ideal for high-speed imaging applications.



Features

- » One push, high-speed, point to point focus
- » Seamless integration with liquid lenses
- » Focus range of millimeters to infinity, in less than 20 ms
- » Easy integration with Pixelink SDK

Benefits

- » Large range of optical variation: Liquid interface allows for large phase shift variations
- » Sturdiness: Tested for over 100 million cycles with zero performance degradation
- » Shock resistance: Excellent output before and after shock tests
- » High-speed: Reconfigures in tens of milliseconds
- » Low power: Dissipates ~15mW, 10x lower than other systems

Applications

- » Bar-Code Reading
- » Biometrics Facial and Retinal
- » Inspection
- » Biotechnology
- » Medical Applications









Select the Camera and Autofocus Lens that Fits Your Application

Pixelink has a full line of USB 3.0 autofocus cameras including:

| Camera Model | Color Space | Sensor | Resolution | Sensor Size | |
|---------------|-------------|-----------------------|------------|-------------|--|
| PL-D721CU | Color | ON Semi Vita 1300 | 1.3 MP | 1/2" | |
| PL-D721MU | Monochrome | ON Semi Vita 1300 | 1.3 MP | 1/2" | |
| PL-D722CU | Color | ON Semi Vita 2000 | 2.3 MP | 2/3" | |
| PL-D722MU | Monochrome | ON Semi Vita 2000 | 2.3 MP | 2/3" | |
| PL-D729MU | Monochrome | ON Semi Mano 9600 | 9.5 MP | 2/3" | |
| PL-D732CU | Color | CMOSIS CMV 2000 | 2.2 MP | 2/3" | |
| PL-D732MU | Monochrome | CMOSIS CMV 2000 | 2.2 MP | 2/3" | |
| PL-D732MU-NIR | Monochrome | CMOSIS CMV 2000 | 2.2 MP | 2/3" | |
| PL-D753CU | Color | Sony IMX421 | 2.8 MP | 2/3" | |
| PL-D753MU | Monochrome | Sony IMX421 | 2.8 MP | 2/3" | |
| PL-D755CU | Color | Sony IMX250 | 5.0 MP | 2/3" | |
| PL-D755MU | Monochrome | Sony IMX250 | 5.0 MP | 2/3" | |
| PL-D775CU | Color | ON Semi Color MT9P006 | 5.0 MP | 1/2.5" | |
| PL-D775MU | Monochrome | ON Semi Mono MT9P031 | 5.0 MP | 1/2.5" | |
| PL-D7715CU | Color | ON Semi MT9F002 | 15 MP | 1/2.3" | |

Liquid Lens Specifications:

| Format | Varioptic C-Mount Lens | | Edmund Optics Liquid Lens Cx Series Focal Length Lenses | | | Varioptic S-Mount Lens (Board Level Only) | | | |
|------------------------------|------------------------|------------|------------------------------------------------------------|-----------|------------|----------------------------------------------|----------|---------------|---------------|
| Effective Focal Length | 16 mm | 25 mm | 12 mm | 16mm | 25 mm | 35 mm | 2.6 mm | 7.5 mm | 9.6 mm |
| Sensor Compatibility | 1/3"- 2/3" | 1/3"- 2/3" | 1/2" | 1/2" | 2/3" | 2/3" | 1/2.5" | 1/4" - 1/2.5" | 1/4" - 1/2.5" |
| Focus Range | 110 mm - ∞ | 120 mm - ∞ | 40 mm - ∞ | 65 mm - ∞ | 125 mm - ∞ | 200 mm - ∞ | 4 mm - ∞ | 7 mm - ∞ | 7 mm - ∞ |

Contact us today for more information on Pixelink autofocus cameras.